


Completely tight

ITS 50 Holder, sealed, also for automatic operation




Ingeniously simple


A simple sealing plate under the 50 Holders fulfils an old wish: ITS chucks are completely sealed.

These holders have a simple gripper slot on the periphery. The corresponding gripper fits all established EROWA Robots.

Existing ITS 50 holders can be retrofitted and put to continued use.



Purchasing or retrofitting



Place the sealing ring over the chuck on the machine table. There are seals for all EROWA chucks.



Purchase or retrofit the ITS 50 Holder.



02 | Sealing plate

Ingeniously simple supplementary plate.

03 | Gripper slot

For the new ITS 50 C Gripper.

04 | Plastic insert

Oil-resistant plastic.

05 | ITS 100 sealing ring

Fixing device for EROWA chucks.





Insert ITS 50 Gripper C on the Robot.



Start manufacturing.

ACTS

More functions - same price
Patented
High degree of process reliability
Simple retrofit
Complete range


EROWAITS

Holder C components


There is an alternative to all previous EROWA ITS 50 products: the ITS 50 C version, which is also fully sealed. All the accessories are listed in the following pages.

It is perfectly possible to convert the products yourself; the retrofit from ITS 50 to ITS 50 C is described with the help of an example on the last few pages of this flyer.


ED 004400	C + 1 - 1 + 50 C
ER-094180	Centering plate 50 C 50 pieces
ER-094181	Centering plate 50 C 5 pieces
	3 pieces
Version	Corrosion-resistant, including sealing plate and 4 suppor-
	ting feet each.
Application	Small electrode weights.
Mounting	Mounted directly on plane surface of blank.



ER-095124	Sealing plate 50 C 50 pieces	
ER-095125	Sealing plate 50 C 5 pieces	
	NOX DE LA CONTRACTION DE LA CO	990
Version	Sealing plate, stainless.	
Application	For retrofitting existing ITS 50 holders	



ER-093758	Uniblank C EWIS™ 12 pieces
	NOX auto
Version	Set of 12 units, fitted without machining of body. With gripper slot and sealing plate.
Application Mounting Note	To mount electrodes and workpieces of various shapes. As required. Order EWIS™ chip, ER-094168 separately.



ER-093765 Prisround C EWIS™

12 pieces

NOX auto


Version Set of 12 units, with gripper slot and sealing plate.

Prepared for receiving the code carrier.

To mount blank parts with shaft size up to 25 mm **Application** Mounting Fit into recess and tighten bolts. If necessary center part

with insert plates ER-010523.

Order EWIS[™], ER-094168 seperatly! Note



ER-093774 Uniholder C EWIS™ 12 pieces

NOX auto



Set of 12 units, including 2 setscrews for each unit. With Version

gripper slot and sealing plate.


Application To mount electrodes and workpieces with a base surface

of up to 20 mm.


Mounting Insert and tighten setscrews. If necessary, center with

spacer plate ER-010532.

Note Order EWIS[™] chip, ER-094168 separately!



ER-093780 Uniplate C EWIS™ 12 pieces








Version Set of 12 units, surface 51 x 51 mm faced, including 2 x

M6 bolts for each unit. With gripper slot and sealing plate.

Application To mount electrodes and workpieces with a base surface

of more than 50 mm.

To fit blank With 2 x M6 bolts into the base surface. Order EWIS[™] chip, ER-094168 separately. Note



EWIS™ rapid chip with chip holder SW14 ER-094168 for holder C








EWIS Rapid chip: read only.


In any EROWA electrode holder and pallet which has been Application


prepared for it.




EROWA ITS

Holder C components







ER-093996	Square 15 holder C 1 pieces	
ER-093997	Square 15 holder C 12 pieces	
Version Application	ITS system size 50. EDM/WEDM.	



ER-093992	Square 25 holder C 1 pieces	
ER-093993	Square 25 holder C 12 pieces	
Version Application	ITS system size 50. EDM/WEDM.	



ER-094046	Compact ITS adapter C
Version	ITS system size 50, lock with central locking bolt. Prepared to accommodate chip holder for EWIS chip.
Operation Application	Tighten central locking bolt. System adapter Compact - ITS.



ER-094063 **Compact ITS adapter chuck C**






ITS system size 50 C, QuickChuck action for Compact Version

holders.

Operation Quick locking mechanism with lever.

Application Individual Compact chuck for machines which are

equipped with standard ITS. System adapter Compact -




	Sealing ring ITS50 C for ITS100 P		
EK-094158	Sealing ring ITS50 C for ITS 100 P automatic		
		 	-



Version Aluminium anodized.

Prevents penetration of chips and dirt into the ITS chuck Application

100 P by application of EROWA electrode holders C.




ER-094112	Sealing ring ITS50 C for SSF manual	
ER-094143	Sealing ring ITS50 C for SSF automatic	




Version Aluminium anodized.

Application Prevents penetration of chips and dirt into the rapid action

chuck by application of EROWA electrode holders C.




ER-092203	Sealing ring ITS50 C for PowerChuck P manual	
ER-092201	Sealing ring ITS50 C for PowerChuck P automatic	
	NOX auto 🚇	
Version	Rust-resistant steel	
Application	Prevents penetration of chips and dirt into the Power-	



Chuck P during machining with EROWA electrode holders





EROWAITS

Holder C components

ER-094093 Sealing ring ITS50 C for PC210




Version

Aluminium anodized.

Application

Prevents penetration of chips and dirt into the ProductionChuck 210 Combi by application of EROWA electrode holders C. For automatic handling with gripper RN PC 210 (option).




ER-094178 Cover set for UPC / ITS 50C



Version

Aluminum with inserts, to protect UPC chuck when used wih holder Ø72, pallet Ø115, pallet Ø148, electrode

holders ITS 50 C.




ER-094955 Sealing ring ITS50 C for Chuck 50









Version

Plastic

Application

Prevents penetration of chips and dirt into the ITS Chuck 50 with application of EROWA HoldersITS50 C.

Appreciation

Sustainability also pays off in economic terms.

Existing ITS 50 Holders can very easily be retrofitted into the "sealed" version. A few details have to be observed in this respect.



Check the general condition of the electrode holders for damage on the chuck body (thread, contact surfaces for blanks), the supporting feet and the centering plates (worn-out punch holes).



Divide the holders to be retrofitted into two groups:

- a) to be fitted with the sealing plate only
- b) entire centering plate to be replaced



Purchase a sufficient number of ER-095124 sealing plates for category a).



Order number of ER-094180 centering plate sets for category b).



Detach the centering plates from the holders by removing the supporting feet (SW8). Clean the parts that will be put to continued use.



Countersink the \emptyset 8.5 mm boreholes to \emptyset 9 mm x 90°.



Fit the sealing plate (with new or existing centering plates and supporting feet) to the existing holder.



CAUTION: it is imperative that the supporting feet be tightened with a torque wrench (e.g. ER-011600). Torque: 8 Nm.



Make sure that the supporting feet are level.



If you use the holder manually on milling machines, you have already done everything that is required.



If the retrofitted ITS 50 Holders C are loaded by means of a Robot, then the gripper slot must now be reworked.



If EWISTM Chips are used for automatic holder identification, then the thread must be fitted to the reference side (chip ER-094168).



Retrofitted EROWA ITS 50 Standard Holders.

The next step

Important things need to be planned. And your next step is certainly among the important things. For it is your start into a new, efficient era. We are pleased to be with you on the way. As consultants, in practice. For you to know at all times what you're engaging in.

The next EROWA branch office is not far – **take the step**.





USA

EROWA Technology, Inc. North American Headquarters 2535 South Clearbrook Drive Arlington Heights, IL 60005 USA Phone 847 290 0295 Fax 847 290 0298 e-mail: info@erowa.com

Italy

www.erowa.com

EROWA Tecnologie S.r.l. Strada Statale 24 km 16,200 IT-10091 Alpignano (TO) Italia Phone 011 9664873 Fax 011 9664875 info@erowa.it

Singapore

EROWA (South East Asia) Pte. Ltd. CSE Global Building No.2 Ubi View, #03-03 Singapore 408556 Singapore Phone 65 6547 4339 Fax 65 6547 4249 sales.singapore@erowa.com

Japan

EROWA Nippon Ltd. Shiba Shimizu Bldg. 2-3-11 Shiba Daimon, Minato-ku 105-0012 Tokyo Japan Phone 03 3437 0331 Fax 03 3437 0353 info@erowa.co.jp www.erowa.co.jp

Switzerland

EROWA AG Knutwilerstrasse 3 CH-6233 Büron Schweiz Phone 041 935 11 11 Fax 041 935 12 13 info@erowa.com www.erowa.com

France

EROWA Distribution France Sàrl PAE Les Glaisins 12, rue du Bulloz FR-74940 Annecy-le-Vieux France Phone 4 50 64 03 96 Fax 4 50 64 03 49 info@erowa.tm.fr

Spain

EROWA Technology Ibérica S.L. c/ Avda. Cornellá, 142 7º 3ª ext. E-08950 Esplugues de Llobregat - Barcelona España Phone 093 265 51 77 Fax 093 244 03 14 erowa.iberica.info@erowa.com

China

EROWA Technology (Shanghai) Co., Ltd. G/F, No. 24 Factory Building House 69 Gui Qing Road (Caohejing Hi-tech Park) Shanghai 200233, PRC China Phone 021 6485 5028 Fax 021 6485 0119 info@erowa.cn

Germany

EROWA System Technologien GmbH Gewerbepark Schwadermühle Rossendorferstrasse 1 DE-90556 Cadolzburg b. Nbg. Deutschland Phone 09103 7900-0 Fax 09103 7900-10 info@erowa.de

Scandinavia

EROWA Technology Scandinavia A/S Fasanvej 2 DK-5863 Ferritslev Fyn Denmark Phone 65 98 26 00 Fax 65 98 26 06 info@erowa.com www.erowa.com

Eastern Europe

EROWA Technology Sp. z o.o. Eastern Europe ul. Spółdzielcza 37-39 55-080 Kąty Wrocławskie Poland Phone 71 363 5650 Fax 71 363 4970 info@erowa.com.pl

India

EROWA Technology (India) Private Limited No: 6-3-1191/6, Brij Tarang Building Unit No-3F, 3rd Floor, Greenlands, Begumpet, Hyderabad 500 016 (Andhra Pradesh) India Phone 040 4013 3639 Fax 040 4013 3630 salesindia@erowa.com